


Fan 110 V

Chassis Wiring Diagram


AC Power Entry Tycho/CORCOM 6EDL1S Cha 3 A SlowBlow fuse	110 VAC ssis GND	Black White Green	Black Fan White EBM-Pab 4530Z	ost
12 V Power Supply set to 13 V	110 VAC	Black White	Orange USB Black Hub	
Power-One HC12-3.4-AG	+12 V DC DC GND	Orange Black	Red LED Black (White) 5102H1-5V	
5 V Power Supply Power-One	110 VAC	Black White	Orange DaqBoar Black A/D	rd
HB5-1.5/OVP-AG or HB5-3/OVP-AG	+5 V DC DC GND	Red Black		
DDS box and power supply	110 VAC	Black White		
	+5 V DC DC GND	Red Black		
RX box and power supply	110 VAC	Black White	Color Code +15 V purple -15 V yellow	
	+5 V DC DC GND	Red Black	+12 V orange +5 V red +3.3 V blue	
TX box	+5 V DC DC GND H12 V DC DC GND	Red Black Orange Black	+1.8 V gray AC: Black and White AC GND: Green DC GND: Black or Tinned E	Braid
RXLO box	+5 V DC DC GND H12 V DC GND	Red Black Orange Black	Note: Power filter has significant voltage drop, run 12 V at 13	3 V
STALO box	+12 V DC DC GND	Orange Black		

A/D board connections




Terminate Samples and TR with 470 ohms and 1Nn5711 diode at the BNC connector.

TX Box




Schematic Diagram Receiver



Paul E. Johnston CIRES/NOAA PSD2

Supply Filter Schematic Diagram Out-of-Date, June 2011



Supply Filter Parts List

Mount (lug-type terminal strip) is Keystone part 823

Mouser 534-823TS, it is also Cinch 55B, or ABBATRON/HH Smith 871

Inductor is 500uH, JW Miller 5256-RC Digi-Key M8274-ND

100 uF cap is Nichicon UHE1H101MPD Digi-Key 493-1605-ND


4.7 uF cap is EPCOS B32522C475J Digi-Key 495-1131-ND

10 nF cap is Murata RPE5C1H103J2K1C03B Digi-Key 490-3673-ND


1 nF cap is Murata RPE5C1H102J2P1A03B Digi-Key 490-3674-ND

Supply filter used in 2009/2010 radars (CFF, STD, NER, and PFD).


2775 STALO Box CH1 thru CHXIV



2775 STALO Box starting CHXV




DDS Box



This box not **Clock Divider Box** Composite Default screen used with new radar controller 3.3 V Synch Clock from DDS from DDS 3.3 V Clock Jumpers: S0: 0 S1: 0 S2: 1 S3: 0 S4: 0 S5: 0 **ANALOG DEVICES** S6: 2/3 AD9513/PCB S7: 0 **Clock Divider Board** S8: 0 S9: 0 S10: 2/3 OUT 2 +5 V +3.3 V 1 8 SN74LVC2T45 6 4 5 **GND** DIR 25 ohm To (33||100)Radar Controller Clock Input **GND**

New Radar Controller



Notes

Sp32 adapter needs to be mounted with pin 1 to pin 1. The connector is smaller than the header, and it is possible to be off a pin.

Cable lengths are important, since phase of pulses and DDS clock can have a race condition if the cables are the incorrect length.

To use the external clock, the internal oscillator must be removed.

100 MHZ cable from radar to computer is 30" 0.141 hardline

Logic cables to Radar are SMA to BNC LMR-195 cables, 60" long.

Cable from Synch clock DDS output to case is 5".

Cable from DDS case to Chassis output is 16", with right angle connector on one end.

4 SMA bulkhead connectors on a blank backplane cover

top connector is .6" from top use .7" spacing